

# DIGITAL THERMOMETER - TE323

## MANUALE D'USO:

To use the DIGITAL THERMOMETER, remove the protective sheath, press the on/off button and insert at least ½" of the stem into the testing area.

### **TEMPERATURE MODE CHOICE:**

Before taking temperature measurements, select either Celsius or Fahrenheit mode. When unit is "off" press and hold the on/off button and the display will alternate between °C and °F, release the on/off button when your desired temperature mode shows in the display. To switch temperature mode, repeat this procedure.

### **HOLD TEMPERATURE VALUES:**

To hold a reading on the display, press the D-H (Data Hold) button. The reading will flash when D-H is in operation. Press the D-H button a second time to return to normal operation.

### **LOW BATTERY INDICATION:**

When a low battery is detected, LOB (Low Battery Indication) will blink alternately with a reading.

### **SWITCHING OFF:**

Press the on/off button to turn off the DIGITAL THERMOMETER. The unit will automatically power off after approximately 35 minutes.

### **SPECIFICATIONS:**

Temperature Range	-58° to 300°F / -50° to 150°C
Resolution	0.1°
Accuracy	±2°F / ±1°C
Sampling Time	1.5 seconds
Battery	1.5V Button